



From Left to Right



How to Determine Swing of Systems:



CONFIGURATION IS ALWAYS DETERMINED WHEN VIEWING SYSTEM FROM EXTERIOR SIDE, GOING LEFT TO RIGHT.

From Left to Right

